INTERACTIVE SCHEMATIC





This document is best viewed at a screen resolution of 1024 X 768.

To set your screen resolution do the following: **RIGHT CLICK** on the **DESKTOP**. Select **PROPERTIES**. **CLICK** the **SETTINGS TAB**. **MOVE THE SLIDER** under **SCREEN RESOLUTION** until it shows **1024 X 768**. **CLICK OK** to apply the resolution

The Bookmarks panel will allow you to quickly navigate to points of interest.



Click on <u>any text that is BLUE and underlined</u>. These are hyperlinks that can be used to navigate the schematic and machine views.

VIEW ALL CALLOUTS

When only one callout is showing on a machine view this button will make all of the callouts visible. This button is located in the top right corner of every machine view page.

HOTKEYS (Keyboard Shortcuts)				
	FUNCTION	KEYS		
+	Zoom In	"CTRL" / "+"		
	Zoom Out	"CTRL" / "-"		
	Fit to Page	"CTRL" / "0" (zero)		
Sur Con	Hand Tool	"SPACEBAR" (hold down)		
	Find	"CTRL" / "F"		



CATERPILLAR®

Schematic

D9R Track-Type Tractor Hydraulic System

ACL1-UP WDM1-UP

COMPONENT LOCATION



Decorintion	Part	Machine	Schematic
Description	Number	Location	Location
Cylinder Gp (Blade Lift)	165-8633	<u>16</u>	<u>E-2</u>
Cylinder Gp (Blade Tilt)	109-6778	<u>17</u>	<u>C-1</u>
Cylinder Gp (Blade Tilt-RH)	109-8832	<u>18</u>	<u>D-2</u>
Cylinder Gp (Blade Tilt-RH)	109-8833	<u>19</u>	<u>F-2</u>
Cylinder Gp (Pin Puller)	6E-3113		<u>E-8</u>
Cylinder Gp (Ripper Lift)	132-5123	<u>20</u>	<u>D-7</u>
Cylinder Gp (Ripper Tilt)	132-5149	Z	<u>D-8</u>
Manifold Gp (Inlet Manifold)	6E-4138	<u>3</u>	<u>D-7</u>
Pump Gp (Piston)	104-1752	1	<u>E-3</u>
Tank Gp	163-4153	<u>12</u>	<u>A-4</u>
Valve (Vacuum Breaker)	154-6165	<u>15</u>	<u>B-4</u>
Valve Gp (Blade and Ripper)	187-8636	<u>2</u>	<u>D-7</u>
Valve Gp (Blade Lift)	6E-5138	<u>6</u>	<u>D-5</u>
Valve Gp (Blade ⊺ilt)	6E-4049	<u>7</u>	<u>C-5</u>
Valve Gp (Charging Valve)	4T-1008	<u>5</u>	<u>D-5</u>
Valve Gp (Dual Tilt)	225-2321	<u>14</u>	<u>C-1</u>
Valve Gp (Quick Drop)	6E-4805	<u>13</u>	<u>F-3</u>
Valve Gp (Relief Valve)	6E-4139	<u>4</u>	<u>D-6</u>
Valve Gp (Relief)	116-1895	<u>10</u>	<u>A-5</u>
Valve Gp (Ripper Lift)	6E-4051	<u>8</u>	<u>B-5</u>
Valve Gp (Ripper Tilt)	187-8637	<u>9</u>	<u>B-5</u>

TAP LOCATION



Tap Number	Description	Schematic Location
<u>A</u>	Implement Pump Discharge	<u>E-3</u>
<u>B</u>	Implement Pump Signal	<u>E-4</u>
<u>HA</u>	Implement Pump Discharge (At Valve)	<u>E-7</u>
<u>HB</u>	Implement Pump Signal (At Valve)	<u>E-6</u>
Ŀ	Oil Sampling (SOS)	<u>A-3</u>



ELECTRICAL SYMBOLS



Hydraulic Symbols (Electrical)









IMPLEMENT CONTROL





LIFT CYLINDERS (QUICK - DROP VALVE)





HYDRAULIC TANK





PIN PULLER ATTACHMENT





RIPPER ATTACHMENT





TILT CYLINDER ATTACHMENT



